

通道数据

Sofe-SD20	10CH Mode1	DMX Value	Function
Dimmer	1	0---255	Darkness----->Bright
Dimmer FINE	2	0---255	
Strobe	3	0---7	Undefined
		8---63	Fast Strobe----->SlowStrobe
		64---71	Undefined
		72---127	Fast Puslation Slow Close--->Fast Puslation Fast Close
		128---133	Undefined
		134---189	Slow Puslation Fast Close--->Fast Puslation Fast Close
		190--195	Undefined
		196--250	Random Strobe
		251--255	Undefined
		Focus	4
Pan(X)	5	0---255	
Pan(X) Fine	6	0---255	
Tilt(Y)	7	0---255	
Tilt(Y) Fine	8	0---255	
P/T Speed	9	0---128	Fastest----->Slowest
		129---170	SlowSpeed (1/3 MaxSpeed)
		171---211	MediumSpeed (1/2 MaxSpeed)
		212---255	Fast Speed (Fastest Speed)
Control	10	0---127	Undefined
		128---153	Undefined
		154---179	Undefined
		180---205	Undefined
		206---231	Undefined
		232---255	Reset ALL(> 3s)