

Ares-S9A	39CH Model1	34CH Mode2	DMX Value	Function
Dimmer	1	1	0---255	Brightness--->Darkness
Dimmer FINE	2		0---255	
Strobe	3	2	0---3 4---103 104---107 108---207 208---212 213---225 226---238 239---251 252---255	Closed Slow Strobe--->Fast Strobe Open SlowPuls---->Fast Puls Open Random Slow Strobe Random Medium Strobe Random Fast Strobe Open
Color	4	3	0---11 12---23 24--- 35 36--- 47 48--- 59 60---71 72--- 83 84---95 96---107 108---119 120--- 131 132---143 144---155 156--- 171 172--- 213 214--- 255	White Color1+White Color1 Color1 + Color2 Color2 Color2 + Color3 Color3 Color3 + Color4 Color4 Color4 + Color5 Color5 Color5 + Color6 Color6 Color6 + White CW Rotation Slow--->Fast CCW Rotation Fast--->Slow
Cyan	5	4	0---255	EXCLUDED---->INSERTED
Magenta	6	5	0---255	EXCLUDED---->INSERTED
Yellow	7	6	0---255	EXCLUDED---->INSERTED
CTC	8	7	0---255	EXCLUDED---->INSERTED
Macro Color	9		0---255	
NULL	10	8	0---255	NULL

Gobo1 Select	11	9	0---9 10--- 20 21--- 29 30---39 40--- 49 50--- 59 60---85 86---111 112---137 138---163 164---189 190---222 223---255	White Gobo1 Gobo2 Gobo3 Gobo4 Gobo5 Gobo1 Shake Slow--->Fast Gobo2 Shake Slow--->Fast Gobo3 Shake Slow--->Fast Gobo4 Shake Slow--->Fast Gobo5 Shake Slow--->Fast CW Rotation Slow---->Fast CCW Rotation Fast--->Slow
Gobo1 Index Rotation	12	10	0---127 128---191 192---255	0° ---->360° (FINE IN 13CH) CW Rotating Slow---Fast CCW Rotation Fast---Slow
Gobo1 Index Rotation FINE	13		0---255	
Fixed Gobo	14	11	0---4 5---10 11---16 17---22 23---28 29---34 35---40 41---46 47---52 53---58 59---74 75---90 91---106 107---122 123---138 139---154 155---170 171--- 186 187--- 202 203---229	White Gobo1 Gobo2 Gobo3 Gobo4 Gobo5 Undefined Undefined Animation Animation Gobo1Shake Slow--->-Fast Gobo2 Shake Slow--->-Fast Gobo3 Shake Slow---->Fast Gobo4 Shake Slow---->Fast Gobo5Shake Slow---->Fast Gobo6 Shake Slow---->Fast Gobo7 Shake Slow---->Fast Gobo8 Shake Slow---->Fast Gobo9 Shake Slow---->Fast CW Rotation Slow---->Fast

